

Description	Material	Finish	
Body	Brass	Nickel	
Socket	BE CU	Gold	
Insulation	PTFE	N/A	
O Ring	SI Rubber	Rubber	
Washer	Brass	Nickel	
Nut	Brass	Nickel	
Spacer	PTFE	N/A Nickel	
Support	Brass		
Heat Shrink	Polyolefin	Black	



O-RING

REVISIONS				
REV	DESCRIPTION	DATE	APPV	
Α	Add heat shrink, new frame,revised stripping instruct./dims	4/21/10	CJ	
В	Updated footprint and dimensions; Added new title block	10-JUL-12	BPM	

## RECOMMENDED CABLE STRIPPING DIMENSIONS



## CONSMA014-R178 ASSEMBLY INSTRUCTIONS

- 1. Strip the cable to the recommended dimensions.
- Slide the coax into the support until the outside insulation bottoms out against the inside shoulder of the support.
- 3. Solder the support onto the braid.
- 4. Place the spacer onto the center conductor.
- 5. Solder or crimp the socket onto the center conductor.
- Insert the socket, center conductor, spacer, and support into the body until the top of the socket is even with the white insulation in the body.
- 7. Crimp the tail of the body onto the support with a 0.093" hex crimp tool.

WARNING: THIS DRAWING CONTAINS PROPRIETARY INFORMATION THAT IS THE SOLE PROPERTY OF LINX TECHNOLOGIES, AND SHALL BE TREATED AS SUCH. NO DISCLOSURE OR REPRODUCTION OF THIS DOCUMENT IS PERMITTED, IN WHOLE OR IN PART, WITHOUT THE EXPRESS WRITTEN PERMISSION OF LINX TECHNOLOGIES OR ITS DESIGNATED AGENTS.

2. DIMENSIONS APPLY AFTER FINISHING.

DESIGNATED AGENTS.

MATERIAL:

TOLERANCES:
.020 [0.50]-200 [5.00]=±.008 [0.20]
.200 [5.00]-1.200 [30.00]=±.016 [0.40]
1.20 [30.0]-4.75 [120.0]=±.024 [0.60]
4.75 [120.0]-12.40 [315.0]=±.040 [1.0]

ANGLES: ±1°

DRAWN: B.MURPHY DT: 10-JUL-12

**ENGR: S.HOGAN** 

DT: 10-JUL-12 SCALE: 2:1

TITLE:

159 ORT LANE MERLIN, OR 97532

SMA FEMALE BULKHEAD MOUNT CABLE END CRIMP WITH O-RING FOR RG178 CABLE

4. SAFETY BREAK ALL SHARP CORNERS AND EDGES .02 MAXIMUM.

SIZE DWG. NO.

CONSMA014-R178

SCALE: 2:1

DO NOT SCALE DRAWING

SHEET 1 OF 1